

FUELING PROCEDURE

- 1. Tie up your boat securely. Shut off the engine.**
- 2. Get everyone off the boat.**
- 3. Shut off all power on the boat. Turn off the battery switches. Turn off any automatic pilot lights. Shut off propane.**
- 4. Close up the boat tight. Make sure all the hatches, doors, ports and vents are closed.**
- 5. Fuel the boat yourself. Make sure the fuel nozzle is in the right opening.**
- 6. Make sure the nozzle stays in metal to metal contact with the fuel fill.**
- 7. Do not to spill fuel or over fill the tank. Clean up spills**
- 8. After fueling open the boat up completely. Open the doors, windows, hatches, ports and the engine room.**
- 9. Check the engine room and bilge for fuel by both looking and sniffing. The best gas detector is your nose. Thoroughly ventilate the boat especially the engine room.**
- 10. Turn the battery switch on and start the engine room blower. Let it run for at least five minutes.**
- 11. Start the engines.**
- 12. Close up the engine room hatch and other doors and hatches you don't want open.**
- 13. Turn on any other power switches and appliances that need to be on.**
- 14. Get everyone back on board.**
- 15. Get underway.**